



# INSTALLATION GUIDE

Thank you for choosing a B-PWR product, designed by passionate riders who focus on what users really need.

## 1. SAFETY INSTRUCTIONS

To avoid any unfortunate situations, we recommend that you get to know how your modified vehicle handles before using it in extreme conditions.

Read all the instructions carefully before installing this product.

If you do not have the tools or technical knowledge needed to ensure proper installation, have the product installed by an authorized dealer.

### ⚠ WARNING

It is essential that you follow the installation procedures, possess general mechanical knowledge and use appropriate tools to ensure a safe and reliable installation.

Improper use or installation of the product, or any modifications made to adapt the product for use in a context other than that for which it was intended, voids the warranty and may result in **SERIOUS INJURIES**.

B-PWR and all its affiliated companies, as well as its suppliers and distributors, are not responsible for any consequences whatsoever resulting from an incorrect installation or an improper use of the product.

This guide provides detailed instructions for installing the product.

### AVAILABLE KIT

PMRB-SLASH-146, PMRB-SLASH-155, PMRB-SLASH-165

### COMPATIBILITY


Polaris snowmobile platform Axys Slash

### ⚠ WARNING

For safety reasons, this kit needs to be installed by a person with general mechanical knowledge using the proper tools.


The illustrations in this document indicate the typical structure of the various assemblies. It is therefore possible that they do not represent the exact form of the parts or the manufacturing details. These illustrations are intended to identify parts that perform an identical or similar function.

## 2. PARTS– PMRB-SLASH-146




PIECE	DESCRIPTION	QTY	PARTS NUMBERS
P1	Rear bumper	1	K05-PMRB-SLASH
P2	M5 X 20 Torx T25 SCREW,	12	
P3	M5X0.8 hexagonal nylon lock nut	12	
P4	Blind rivet AB6-6A, 3/16 diameter, thickness ,250-,375	14	
P5	M5 Washer	6	

# PMRB-SLASH-155



PIECE	DESCRIPTION	QTY	PARTS NUMBERS
P1	Rear bumper	1	
P2	M5 X 20 Torx T25 SCREW,	10	K05-PMRB-SLASH
P3	M5X0.8 hexagonal nylon lock nut	10	
P4	Blind rivet AB6-6A, 3/16 diameter, thickness ,250-,.375	4	
P5	M5 Washer	4	

# PMRB-SLASH-165



PIECE	DESCRIPTION	QTY	PARTS NUMBERS
P1	Rear bumper	1	
P2	M5 X 20 Torx T25 SCREW	12	K05-PMRB-SLASH
P3	M5X0.8 hexagonal nylon lock nut	12	
P4	Blind rivet AB6-6A, 3/16 diameter, thickness ,250-,375	6	
P5	M5 Washer	6	

### 3. VEHICLE PREPARATION

- 3.1 Read all the instructions carefully before installing the product.
- 3.2 Make sure you have enough space to work properly.
- 3.3 Make sure to have the required tools.
- 3.4 Refer to vehicle owner's manual for removal of various panels and other parts.

### 4. INSTRUCTIONS

*Note: Unless differences occur between left hand (LH) and right hand (RH) sides, the procedures are shown for only one side of the vehicle. Repeat for other side. Right and left sides are defined as when sitting on the vehicle.*

- 4.1 Slide rear bumper [P1] in position on vehicle as shown.

*Note: If there are rivets at the bumper anchor points, remove them.*



- 4.2 Locate rear bumper [P1] with M5 X 20 Torx T25 SCREW [P2] and M5X0.8 hexagonal nylon lock nut [P3]. Hand tighten only.

Note -1: Some screws require washer [P5] inside the tunnel. (See exploded view)

Note -2: The direction of the last bumper screw is inwards. (See exploded view)





4.3. Tighten to specification M5 X 20 Torx T25 SCREW [P2].



TIGHTENING TORQUE	
M5 Nylon Lock Nut [P3]	10 N•m ± 2 N•m

4.4. Drill holes in front of the tunnel using bumper as a template with drill bit 3/16" as shown.



4.5 Secure front of bumper with 3/16" rivets [P4] in previously drilled holes as shown and using hand riveter.



End Installation